PROMISE TECHNOLOGY, INC.

It's ALL About Your Data.

ATA RAID 0, 1 Network Attached Storage

ConnectStor™ II

Why settle for anything less than maximum storage flexibility, performance, and economy inside a network attached storage device? Promise ConnectStor II lets network administrators use their own dual Ultra ATA/100 drives and configure them in an ATA RAID 0 (striping) array for huge, instant storage capacity or RAID 1 (mirroring) array for continuous data protection. Just install your drives, attach to your network using the included Ethernet cable, and ConnectStor II does the rest with instant drive recognition, array setup, and formatting of drives.

ULTRA ATA/100

Powered By PROMISE ATA RAID™

- **Adds Instant RAID 0 or 1 Storage for Most Major Networks**
- **Builds Huge RAID 0 Storage Capacity with 2 Drives**
- **Constantly Protects Drive Data Using RAID 1**
- **Add Any Two Ultra ATA/100 Drives for Flexibility, Economy**

Instant Network Storage The Way You Want . . . It's Your Data

For most major network operating systems, ConnectStor II gets you up and running in minutes, not hours (or even days). Just add drives and plug in. The internal BIOS quickly sets up your choice of RAID 0 or RAID 1 array. That's it. Simply manage ConnectStor II with Promise's powerful web-based user interface. Create folders, permissions, and users for added network protection. It's that easy and reliable.

Ultimate Storage Choices

Instant network storage is great, but other competitive NAS products make you pay a premium for their pre-installed hard drives. Not so with ConnectStor II. We let you choose and install your own drives. Take advantage of the very latest Ultra ATA/100 drives available for maximum capacity, speed, and economy. Just remember to get two drives with all the money you're saving. It's all part of the Promise ATA RAID experience. Did we mention you also get to choose which RAID level to use?

CONNECTSTOR II™
ATA RAID 0, 1 NETWORK ATTACHED STORAGE

Complete Array Access Control

ConnectStor II offers sophisticated password-protected management tools to let you monitor and regulate users who access the ConnectStor II subsystem. Promise web-based management software lets you control access levels on a group or individual basis. For faster setup on Windows NT or 2000, ConnectStor II passes through all existing network access permissions so you don't have to reproduce them. Limits storage per user with a built-in quota feature. ConnectStor II even emails designated network administrators/users for pre-designated events such as array and disk errors.

The Leader in ATA RAID

Since 1988 Promise Technology, Inc. has offered high performance ATA controllers for PC storage and has been recognized as the creator and leader of ATA RAID since 1997. The world's biggest OEMs and resellers look to Promise for ongoing innovations in ATA RAID design as the company continues to create the most powerful and economical alternatives to traditional RAID controllers and subsystems.



Expand your network storage quickly and easily. Simply attach ConnectorStor II to an available Ethernet connection, and ConnectStor II does the rest. Configure and monitor ConnectStor II via internet with its easy-to-use browser-based utility.

CONNECTSTOR II SPECIFICATIONS

Number of Drives Possible	Accepts up to 2 Ultra ATA/100, Ultra ATA/66, or Ultra ATA/33 drives by user; Formats new drives automatically on reboot
RAID Levels	RAID 0 (striping), RAID 1 (mirroring)
IP Address Support	Supports automatic assignment of internet addresses by network server (BOOTP or DHCP); IPassign™ software manually assigns IP addresses over network if automatic assignment not supported by network
SMB Management for Windows Operating Systems	Create/Edit/Delete individual and group access to data folders; Create/Edite/Delete shared directories; Passes through existing NT Domain users and access permissions
NFS Management for UNIX/Linux	Assign mount points, user access for directories
Cable Connections	Built-in auto-sensing 10Base-T/100Base-TX network connection using standard RJ45 jack
UPS Support	COM2 port supports attachment of APC-standard Uninterruptible Power Supply
Status Displays	LEDs display power, network activity, disk activity
Operating System Support	Windows Millennium/98/95; Windows 2000/NT4; UNIX, Linux
Housing Assembly Size	2.6 x 11.7 x 9.8 (inches)
Agency Certifications	CE, FCC Class B, BSMI
Warranty	2 years

P/N: C6130CON2000000

PROMISE® TECHNOLOGY, INC.

Promise USA
1745 McCandless Drive • Milpitas, CA 95035
Tel: 800-888-0245 or 408-228-6300
Fax: 408-228-6400 • E-mail: sales@promise.com

Meet us on the web
www.promise.com

Promise Europe
Unit 1.25 European Business Centre • Luchthavenweg 81
5657 EA Eindhoven, The Netherlands
Tel: 31 (0)40 235 2600 • Fax: 31 (0)40 256 9463
E-mail: sales@promise.nl

Promise Taiwan
2F, No. 30, Industry E.Rd. 9
Science-Based Industrial Park
Hsin-Chu, Taiwan, R.O.C
Tel: 886 3 578 2395 • Fax: 886 3 564 5313
E-mail: sales@promise.com.tw

Promise China
Room 3213, No. 11 South Zhong Guan Cun Street
Hai Dian District, Beijing 100081 P.R. China
Tel: 86 10 68723941~2 • Fax: 86 10 68723940
E-mail: sales-china@promise.com